


MAQUINA	DESCRIPCION
QCGCM3218	GRAPADORA 32-18 MECANICA

DESDE FECHA	22/02/12
HASTA FECHA	31/12/2099

HAAH-19-32



2012/02/22



MAQUINA	DESCRIPCION	DESDE FECHA	22/02/2012
QCGCM3218	GRAPADORA 32-18 MECANICA	HASTA FECHA	31/12/2099

RECAMBIO	DESCRIPCION	CANTIDAD	POSICION
RM02HAHP22 (001)	CARCASA HAH-P22	1	1
RM02A01102701 (002)	MANGO A01102701	1	2
RM02A00300301 (003)	EMPUÑADURA A00300301	1	3
RM02A01103001 (004)	LEVA A01103001	1	4
RM02A00300501 (005)	PASADOR A00300501	1	5
RM02A00300601 (006)	TORNILLO A00300601	1	6
RM02A01102801 (007)	PLACA A01102801	1	7
RM02A01102901 (008)	MUELLE A01102901	1	8
RM02A02100501 (009)	MANGO A02100501	1	9
RM02A00301001 (010)	REGULADOR A00301001	1	10
RM02A00301101 (011)	REGULADOR A00301101	1	11
RM02A00101801 (012)	AMORTIGUADOR A00101801	1	12
RM02A01102502 (014)	PLACA A01102502	1	14
RM02A00102102 (015)	UÑA A00102102	1	15
RM02A00102202 (016)	UÑA A00102202	1	16
RM02A00102301 (017)	SOPORTE A00102301	1	17
RM02A00102401 (018)	GUÍA A00102401	1	18
RM02A00301902 (019)	GRUESO A00301902	1	19
RM02A01201706 (020)	CUCHILLA A01201706	1	20
RM02A00102702A (021)	GRUESO A00102702A	1	21
RM02A02100407A (022)	CARCASA A02100407A	1	22
RM02HAA1932P7SD (023)	CARGADOR HAA-19-32-P7-SD	1	23
RM02A01102403 (024)	MUELLE A01102403	1	24
RM02A01102201 (025)	GANCHO A01102201	1	25
RM02A00103710A (026)	EMPUJADOR A00103710A	1	26
RM02A00103501 (027)	RODILLO A00103501	1	27
RM02A00103401 (028)	FLEJE A00103401	1	28



MAQUINA	DESCRIPCION	DESDE FECHA	22/02/2012
QCGCM3218	GRAPADORA 32-18 MECANICA	HASTA FECHA	31/12/2099

RECAMBIO	DESCRIPCION	CANTIDAD	POSICION
RM02A00607101 (029)	TUERCA A00607101	1	29
RM02A00103903A (030)	GUÍA A00103903A	1	30
RM02A00103203 (031)	RODILLO A00103203	1	31
RM02A00103904A (032)	GUÍA A00103904A	1	32
RM02A00607502 (033)	SOPORTE A00607502	1	33
RM02A00105001 (034)	ARANDELA A00105001	1	34
RM02BAA050020 (501)	PASADOR BAA050020	1	501
RM02BAC0404062 (502)	TORNILLO BAC0404062	1	502
RM02A00104701 (503)	PASADOR A00104701	1	503
RM02BAC0306142 (504)	MUELLE BAC0306142	1	504
RM02BAC0605142 (505)	PERNO BAC0605142	1	505
RM02BAC0605122 (506)	TORNILLO BAC0605122	1	506
RM02BAA030010 (507)	PASADOR BAA030010	1	507
RM02BAC0605142 (508)	PERNO BAC0605142	1	508
RM02A00106201 (510)	TORNILLO A00106201	1	510
RM02A00104501 (511)	PASADOR A00104501	1	511
RM02A00104602 (512)	PASADOR A00104602	1	512
RM02BAC0604102 (513)	PERNO BAC0604102	1	513
RM02BAA060016R (515)	PASADOR BAA060016-R	1	515
RM02BAD01041 (516)	TUERCA BAD01041	1	516
RM02BAC0404202 (517)	TORNILLO BAC0404202	1	517
RM02BAA040016 (520)	PASADOR BAA040016	1	520
RM02BAC0204062 (521)	TORNILLO BAC0204062	1	521